

CHRYSLER ADAPTER KIT BIG BLOCK WITH 6 BOLT CRANK **PART #980050**

List of Enclosed Parts:

- (1) #980053 Aluminum Adapter Plate
- (1) #980052 SFI Approved Flywheel 6 Bolt
- (1) #980051 Crankshaft Adapter 6 Bolt
- (4) 3/8 -16 x 1 1/4 Flathead Screws
- (6) 7/16 -20 x 1 Flywheel Bolts
- (6) 3/8 x 1 5/8 Transmission Mounting Studs
- (6) 3/8 - 24 Hex Nuts
- (6) 3/8 Washers
- (2) 7/16 -14 x 1 Starter Bolts
- (2) 7/16 x .620 Dowel Pins

This adapter is designed to be used with a Powerglide/TH350/TH400 converter that measures 1/4" longer than standard General Motors dimensions and is built with a 10-3/4" bolt circle. When installing the supplied flexplate, first place the crankshaft adapter on the crank, and then bolt the flexplate on with the supplied bolts. To ensure proper transmission alignment, proper dowel pins must be located in your engine and the adapter plate. These dowel pins will be used to locate the adapter to the engine and the transmission to the adapter. It is recommended that never-seize to be used on the flathead screws, which attach the adapter to the engine. The adapter plate may be trimmed to better fit your chassis.

FOR TECHNICAL QUESTIONS, PLEASE FEEL FREE TO CALL (765) 456-3957

