

CHRYSLER ADAPTER KIT BIG BLOCK WITH 8 BOLT CRANK
PART #980060

List of Enclosed Parts:

- (1) #980053 Aluminum Adapter Plate
- (1) #980062 SFI Approved Flywheel 8 Bolt
- (1) #980061 Crankshaft Adapter 8 Bolt
- (4) 3/8-16 X 1 1/4 Flathead Screws
- (8) 1/2-20 X 1 Flywheel Bolts
- (6) 3/8 X 5/8 Transmission Mounting Studs
- (6) 3/8 AN Washers
- (6) 3/8-24 Hex Nuts
- (2) 7/16-14 X 1 Starter Bolts
- (2) 7/16-14 X 1 1/2 Bottom Block Bolts
- (2) 7/16 X .620 Dowel Pin

Adapter is designed to use standard powerglide converter dimensions + 1/4".
Crankshaft spacer is placed on crankshaft first, then flywheel is bolted on.

FOR TECHNICAL QUESTIONS, PLEASE FEEL FREE TO CALL (765) 456-3957

